



# High Power Emergency Flashing Lamps

- 14 Flash Patterns
- 3M Tape/Screw Fitting
- Synchronising Wire
- High Powered 3 Watt LEDs
- SAE J595 Class 1
- IP67 100% Waterproof
- 3 Year Warranty

**14 Flash  
Patterns**  
**IP67  
Protection**  
**3 Year  
Warranty**




Part No. 120035RM



Part No. 120035BM



Part No. 120035WM



Part No. 120035AM



Clear Lens when Inactive

**Function** Emergency Lamp

**Size** 131mm x 30mm x 8mm


**Voltage** Multivolt 12-24V

**LED Qty** 6 x 3 Watt

**Cable** 25cm

Draw	Constant	Strobe
@13.8V	0.29A	0.72-0.005A
@28V	0.153A	0.36-0.008A

**Approvals** ECE R10 Compliant  
SAE J595 Class 1 W-1 16DOT  
Flash Patterns 8-12 only\*




## Fitting Instructions

Mount horizontally or vertically onto a flat surface using 3M tape and screws supplied. Please see following page for a detailed description with wiring, flash selection and synchronising procedure.

**Wire Colours:** Red - Power, Brown - Flash Select/Synchronise, Black - Earth


Flash Pattern Selection*			
<b>1</b>	Constant On	<b>8</b>	Single all (SAE)
<b>2</b>	Single (2Hz)	<b>9</b>	Double all (SAE)
<b>3</b>	Double (2Hz)	<b>10</b>	Quad all (SAE)
<b>4</b>	Quad (2Hz)	<b>11</b>	Quint all (SAE)
<b>5</b>	Random	<b>12</b>	Ultra all (SAE)
<b>6</b>	Double (Split)	<b>13</b>	Single-Quad all
<b>7</b>	Quad (Split)	<b>14</b>	Constant/Double

# Flash Selection




1. Connect Red wire to power and Black wire to earth to power the lamp.
2. Tap Brown wire to power to cycle through the 14 flash patterns.
3. Hold Brown wire to power for 7 seconds to reset to the start (Constant Flash Pattern #1).

# Simultaneous or Alternating Flash (when using multiple units)




1. To enter grouping mode, connect all Red and Brown wires together, then connect to power. Each lamp will flash to identify which group they belong to. *Single Flash = Group 1, Double Flash = Group 2.*



2. While maintaining power to Red wires, remove the Brown wires from power.
3. To change groups, tap Brown wire to power.

**Note: Lamps that are set to the same group will flash simultaneously. Lamps that are in opposite groups will alternate flash.**



4. Once lamps are in desired group, disconnect Red wires from power then reconnect to power to exit grouping mode.
5. Connect all brown wires together to synchronise lamps. (Hold all brown wires to power for 7 seconds to reset all flash patterns to start)

**NOTE: Maximum of 20 lamps can be Synchronized together.**